


ELECTRIBE



RHYTHM SYNTHESIZER

ER-1 Owner's Manual



Thank you purchasing the Korg ELECTRIBE·R ER-1. In order to enjoy long and trouble-free use, please read this manual carefully and use the instrument correctly.

KORG

To ensure long, trouble-free operation, please read this manual carefully.

Precautions

Location

Using the unit in the following locations can result in a malfunction.

- In direct sunlight
- Locations of extreme temperature or humidity
- Excessively dusty or dirty locations
- Locations of excessive vibration

Power supply ⊕Ⓢ⊖

Please connect the designated AC adaptor to an AC outlet of the correct voltage. Do not connect it to an AC outlet of voltage other than that for which your unit is intended.

Interference with other electrical devices

This product contains a microcomputer. Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Handling

To avoid breakage, do not apply excessive force to the switches or controls.

Care

If the exterior becomes dirty, wipe it with a clean, dry cloth. Do not use liquid cleaners such as benzene or thinner, or cleaning compounds or flammable polishes.

Keep this manual

After reading this manual, please keep it for later reference.

Keeping foreign matter out of your equipment

- Never set any container with liquid in it near this equipment. If liquid gets into the equipment, it could cause a breakdown, fire, or electrical shock.
- Be careful not to let metal objects get into the equipment. If something does slip into the equipment, unplug the AC adaptor from the wall outlet. Then contact your nearest Korg dealer or the store where the equipment was purchased.

THE FCC REGULATION WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the user's authority to operate this equipment.

CE mark for European Harmonized Standards

CE mark which is attached to our company's products of AC mains operated apparatus until December 31, 1996 means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC). And, CE mark which is attached after January 1, 1997 means it conforms to EMC Directive (89/336/EEC), CE mark Directive (93/68/EEC) and Low Voltage Directive (73/23/EEC).

Also, CE mark which is attached to our company's products of Battery operated apparatus means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC).

Contents

1. Introduction	6
Main features	6
About the data you create on the ER-1	6
Make connections and play!	7
Example connections	7
Preparing to play	7
2. Front and rear panel	8
Synthesizer section	8
Part Select section	9
Common section	9
Sequence Control section	10
Step Key section	10
Connector section	11
3. Basic operation (Quick Start)	12
Conceptual diagram of the ER-1	12
Listening to a Song	12
Listening to Patterns	13
Trying out the functions	13
Changing the tempo of a song or pattern	13
• Using the dial to change the tempo	13
• Using the Tap Tempo key to change the tempo	13
Striking keys to play Parts	14
Modifying (editing) the sound	14
Striking the part keys along with a song or pattern	15
Modify (edit) the sound along with a song or pattern	15
Modifying (editing) a rhythm pattern	16
• Using the step keys to edit the rhythm (Step Recording)	16
• Using the part keys to edit the rhythm (Realtime Recording)	17
Saving a pattern that you create	17
Using a Motion Sequence	18
Connecting various sources to the audio inputs	19
Playing with Pattern Set	20
Using the ER-1 as a tone generator module	20
Synchronized playback with the EA-1	21
4. Pattern mode	22
Selecting a pattern	22
Setting the playback tempo	22
• Using the dial to change the tempo	22
• Using the Tap Tempo key to change the tempo	22

Playing a pattern (Pattern Play)	22
The timing at which patterns will change	22
Playing from the beginning of a pattern (Reset & Play)	22
About the tempo when the pattern is changed	22
Selecting parts	23
The Part Mute function	23
The Part Solo function	23
Creating a pattern	24
Editing the sound of a part	24
Oscillator and amp parameters	24
DELAY	25
Modulation	25
Length, Scale/Beat settings	26
Swing settings	26
Creating a Rhythm Pattern	27
• Using the step keys (Step Recording)	27
• Using the part keys (Realtime Recording)	27
Adding accents to the rhythm pattern (Accent)	27
Motion sequence	28
Playing a motion sequence	28
Recording a motion sequence	28
Playing a delay motion sequence	28
Recording a delay motion sequence	28
Checking motion data	28
Convenient functions for editing patterns	29
Erasing rhythm pattern data from a part	29
• Erasing data during playback or recording (Erase)	29
• Erasing all data from a part (Clear Part)	29
Moving data within a part (Move Data)	29
Copying a part (Copy Part)	30
Data Copy within a pattern	30
Erasing part or delay motion sequence data (Clear Motion)	30
Pattern Set	31
Using Pattern Set to perform (Pattern Set Play)	31
Registering a pattern for Pattern Set	31
Saving a pattern (Write)	32


5. Song mode

Selecting a song	33
Setting the playback tempo	33
• Using the dial to set the tempo	33
• Using the tap tempo key to set the tempo	33
Playing a song (Song Play)	33
Fast-forward or rewind a song	33
Switching songs	33
Playing from the beginning of a position or song (Reset & Play)	33

Creating a song	34
Creating a song from scratch	34
Erasing song data (Clear Song)	34
Specifying a pattern for each position	34
Editing a song	35
Inserting a pattern at a specified position (Insert Pattern)	35
Deleting a pattern from a specified position (Delete Pattern)	35
Changing the pattern for a specific position	36
Recording performances or knob movements into a song (Event Recording)	36
Deleting event data from a song (Clear Event)	37
Checking for song event data	37
Saving a song (Write)	37
6. Global mode	38
Metronome settings	38
Adjusting the volume of the Audio In	38
Synchronizing the ER-1 with external MIDI devices (MIDI Clock)	38
Synchronizing the ER-1 to a master external MIDI device (Ext)	38
Synchronizing an external MIDI device to the ER-1 as master (int)	39
Protect settings (Memory Protect)	39
Saving the settings you modify in Global mode (Write)	39
7. MIDI mode	40
MIDI channel settings (MIDI ch)	40
Setting the MIDI note number for each part (Note No.)	40
Transmit/receive dump data (MIDI Data Dump)	40
MIDI filter settings	41
Saving the settings you modify in MIDI mode (Write)	41
8. Appendices	42
About MIDI	42
Troubleshooting	43
Error messages	44
Restoring the factory set data	44
Specifications	44
Example sounds	45
Blank chart	46
Index	48
Pattern Name List	50
Song Name List	50
MIDI Implementation Chart	51

Make connections and play!

Example connections



Preparing to play

⚠ Be sure to turn off the power before making connections. Careless operation may damage your speaker system or cause malfunctions.


1. Connect the included AC adapter to the DC 9V jack, and plug the adapter into an AC outlet.

⚠ As shown in the above diagram, hook the AC adapter cable around the adapter cable holder. When removing the cable from the holder, do not use excessive force.

2. Connect one end of your audio cables to the line out jacks of the ER-1 (L/MONO, R), and connect the other end to your mixer or powered monitor speakers (amplified speakers) etc. If you will be listening in mono, use the L/MONO jack. To take full advantage of the ER-1's sound quality, we recommend that you listen in stereo.

3. If you will be using headphones, connect them to the headphone jack.

⚠ The output from the line out jacks will not be switched off even if headphones are plugged in.



4. When you have finished making connections, turn on the power. Slightly raise the master volume of the ER-1, and strike the part keys (PERCUSSION SYNTHESIZER 1...4) to check whether connections have been made correctly. Use the master volume of the ER-1 and the gain and fader controls of your mixer or powered monitor system to adjust the volume to an appropriate level.

Part Select section

1. Ring Mod (ring modulation key)

This key switches modulation between parts (ring modulation) on/off.

2. Crash (crash part key)

This key selects the cymbal part. When you press this key, the crash cymbal will sound.

3. H.Clap (handclap part key)

This key selects the handclap part. When you press this key, the handclap will sound.

4. PERCUSSION SYNTHESIZER 1..4 (percussion synthesizer part keys)

These keys select the percussion synthesizer parts. When you press one of these keys, a percussion synthesizer part will sound.

5. AUDIO IN 1, 2 (audio in part keys)


These keys select the audio in parts. When you press one of these keys, an external audio input will be heard.

6. HI-HAT [Close, Open] (hi-hat part key)

This key selects the hi-hat part. When you press this key, the hi-hat will sound.

7. ACCENT (accent part key)

This key selects the accent part.



Common section

1. MASTER VOLUME

This knob adjusts the volume that is output from the line out jacks and the headphone jacks.

2. AUDIO IN THRU

This key allows the external audio input to be output directly from the line out jacks and the headphone jack.

When this key is on, settings of the audio input part other than pan and level will be ignored.

3. Display

This shows the value of the currently selected parameter, and various messages.

4. Dial

Use this to modify the value shown in the display.

5. Peak LED

This indicates the peak level for the input signal from the audio in jacks. Adjust the output level of your external device so that the LED lights only at the maximum level.

6. Beat LED


This will blink at quarter-note intervals to indicate the tempo.

7. [▲][▼] (cursor keys)

In each mode, use these keys to select parameters from the matrix shown in the display.

8. Matrix

The parameters that will appear in the display are listed here for each mode. Use the cursor keys to make the desired parameter select LED light.



4. Pattern Set key

By holding down this key and pressing one of the step keys, you can switch to the pattern that you registered for that key.

5. Shift key

This key is used in conjunction with other keys. When held down, it gives an additional function to another key.

Shift + Play/Pause key: Playback from the beginning of the pattern.

Shift + Rec key: During playback, erase triggers from the pattern.

Shift + Part keys: Select a part without sounding it.


Shift + Step keys: Execute the function shown below each step key.

Shift + dial: If the Shift key is held down as you rotate the dial, the value in the display will change in steps of ten.

Shift + pattern set key: The Pattern Set function will be held (maintained).

For other Shift key combinations, refer to the explanation of each parameter.

Connector section



1. Power switch

This switch turns the power on/off. Each time you press it, the power will alternate on or off.

2. DC 9V

Connect the included AC adapter here.

3. Adapter cable holder

Hook the adapter cable around this so that it will not be disconnected accidentally.

4. MIDI connectors

IN MIDI data is received at this connector to control the ER-1 from an external MIDI device or to receive a data dump.

OUT MIDI data is transmitted from this connector to control an external MIDI device or to transmit a data dump.

THRU MIDI data received at the **MIDI IN** connector is re-transmitted without change from this connector. This is used to "daisy-chain" multiple MIDI devices.

5. AUDIO IN 1, 2 jacks

These jacks are used for the audio-in parts. Sound that is input here can be used as the sound of the AUDIO IN 1 and 2 part selector keys.

6. L/MONO, R (line output) jacks

Connect your audio cables from these jacks to your mixer or powered monitor system (powered speakers) etc. If you wish to make monaural connections, connect the **L/MONO** jack.


7. (headphone jack)

A set of stereo headphones fitted with a stereo jack plug can be connected here.

3. Basic operation (Quick Start)

Conceptual diagram of the ER-1

On the ER-1, a song consists mainly of Patterns (which consist of Parts and delay settings) and event data (refer to p.36 "Recording performances or knob movements to a song (Event Recording)").




Listening to a Song

1. Press the Song Mode key to enter Song mode (the key will light).
2. Use the cursor [▲][▼] keys to make the parameter select LED indicate **Song** (the top LED).
3. Rotate the dial to select the desired song (S01...S16).
4. Press the Play/Pause key to playback the song (the key will light). When the song ends, playback will stop automatically (the key will go dark).


To pause during playback, press the Play/Pause key (the key will blink). To resume playback, press the Play/Pause key once again (the key will light). To stop playback, press the Stop/Cancel key.

It is not possible to change songs during playback.




What is a Song?

On the ER-1, a song is musical data consisting of Patterns arranged in the desired playback order. The ER-1 lets you create and store up to sixteen songs. In each song you can arrange up to 256 patterns, and rhythm and knob movements can also be recorded in addition to the playback. (Refer to p.33 "Song mode.")



Listening to Patterns

1. Press the Pattern mode key to enter Pattern mode (the key will light).
2. Use the cursor [▲][▼] keys to make the parameter select LEDs indicate **Pattern** (top).
3. Rotate the dial to select the desired pattern (A01...A64, b01...b64, C01...C64, d01...d64).
4. Press the Play/Pause key to playback the pattern (the key will light).
When pattern playback ends, the pattern will return to the beginning, and continue playing repeatedly.




To pause during playback, press the Play/Pause key (the key will blink). To resume playback, press the Play/Pause key once again (the key will light). To stop playback, press the Stop/Cancel key. You can rotate the dial to select patterns when playback is stopped or even during playback.

When you change patterns during playback, the change will actually occur at the end of each pattern. (Refer to p.22 "The timing at which patterns will change.")

What is a Pattern?

A pattern is a unit of musical data consisting of sounds arranged in a rhythm. On the ER-1 you can create and save 256 patterns. Each pattern consists of eleven parts (refer to p.14). In addition to the sounds of each part, you can also record rhythms and knob movements (refer to p.22 "Pattern mode").





Trying out the functions

Changing the tempo of a song or pattern

There are two ways to change the tempo. The tempo that you change here will return to the original tempo when you stop playback and switch to a different pattern or song.


• Using the dial to change the tempo

1. Press the Mode key to enter Song mode or Pattern mode.
2. Use the cursor [▲][▼] keys to set the parameter select LED to **Tempo**.
3. Rotate the dial to change the tempo.




• Using the Tap Tempo key to change the tempo

While a song or pattern is playing, press the Tap key three times or more at the desired tempo. The ER-1 will detect the interval at which you pressed the Tap key, and will set the tempo accordingly. The tempo can also be changed in this way even if the ER-1 is not currently playing a song or pattern. Use the cursor [▲][▼] keys to make the parameter select LEDs indicate **Tempo**, and the tempo you modified will appear in the display.




Striking the part keys along with a song or pattern

1. In Song mode or Pattern mode, press the Play/Pause key to begin playback.
2. As you listen to the song or pattern, strike the part keys to play along.



Modify (edit) the sound along with a song or pattern

1. In Song mode or Pattern mode, press the Play/Pause key to begin playback.
2. Press a part key (the key will light) to select the part that you wish to edit.
3. Use the knobs and keys of the Synthesizer section to modify the sound. The sound of the part that is playing will be modified as you move the knobs or keys.



You can press other part keys to edit other parts.

To save the pattern sounds that you modify here, use the Write operation (refer to p.17 "Saving a pattern that you create").



If you re-select a pattern or turn off the power without performing the Write operation, the sound will return to its unedited state.

 **It is not possible to write the sounds you edit in a Song. Only in a Pattern can you write the edited sounds.**

• **Using the part keys to edit the rhythm (Realtime Recording)**

If you wish to hear the metronome while you record, refer to p.38 "Metronome settings."

1. Press the Pattern Mode key (the key will light). Use the cursor [▲][▼] keys to make the parameter select LED indicate **Pattern**.
2. Rotate the dial to select the pattern that you wish to edit.
3. Press the Rec key to enter record-ready mode (the Rec key will light, and the Play/Pause key will blink).
4. Press the Play/Pause key to start the pattern (the Play/Pause key will light).
5. Strike the part keys at the desired rhythm. The pattern will continue playing back repeatedly, so you can continue recording additional material as long as the Rec key remains lit.
6. Press the Stop/Cancel key to stop recording. (The Rec key and Play/Pause key will go dark.) You can also press the Rec key without pressing the Stop/Cancel key, to stop recording but continue playback. (The Rec key will go dark, and the Play/Pause key will be lit.)




If you wish to save the pattern that you created, press the Write key. (Refer to "Saving a pattern that you create," below.)

⚠ The time that an audio part is heard (i.e., the gate time) is determined not by how long you continue pressing the key, but by the Decay value (p.19 "Connecting various sources to the audio inputs").

Erase

If you accidentally input a wrong note, you can hold down the Shift key and Rec key while the pattern continues playing to erase the rhythm pattern for the currently selected part (i.e., the part whose part key is lit).




Saving a pattern that you create

⚠ With the factory settings, memory protect will be on, and it will not be possible to save data. Before you save data, you must turn off the Memory Protect settings in Global mode. (Refer to p.39 "Protect settings.")

Please be aware that when you save data, the pattern in the save destination will be overwritten.

1. Edit a pattern as described in "Modifying the sound" or "Modifying (editing) a rhythm pattern."
2. Press the Write key once (the key will blink). The display will blink to indicate the pattern number.
3. Rotate the dial to select the pattern number in which the data will be saved (i.e., the "save destination").
4. Press the Write key once again to begin saving the data. While the data is being saved, the key will blink. When saving is complete, the key will go dark.



If you decide to cancel, press the Stop/Cancel key. If you do not wish to save the pattern you created, simply select a different pattern without performing the Write operation.


⚠ Never turn off the power while data is being saved to memory (i.e., while the Write key is lit). Doing so may damage the data.

It is not possible to Write data during playback or recording.

Connecting various sources to the audio inputs


Let's try connecting various types of audio device (radio, or MD or CD player) or tone generator to the audio input jacks. Sound that contains no drums is most effective. Try out various types of sounds or music. Depending on the content, you may discover unexpectedly interesting results.

1. Connect an audio device etc. to the audio inputs of the ER-1. Each jack is monaural, so you may need to use a stereo-mono adapter plug, depending on the device you are connecting.
2. Adjust the output level of the connected device so that the peak LED lights only at the maximum levels. At this time you can turn on the Audio In Thru key (the key will light) to hear the input sound without having to press the part key.
3. Select the pattern or song whose volume you wish to adjust, and press the Play/Pause key to begin playback.
4. Press the Mode key to enter Global mode.
5. Use the cursor [▲][▼] keys to set the parameter select LED to **Input Gain 1**.
6. Rotate the dial to adjust the input volume to create a balance with the volume of the other parts.



Adjust **Input Gain 2** in the same way.

The input sound will be heard while you press the Audio In part key. The Audio In parts that are recorded in a pattern or song do not produce the sound that was being input when the parts were being recorded; they simply allow the sound that is received in the audio input at that moment to be heard from when the trigger is turned on, for the duration set by the **Decay** knob.



If you wish to strike Audio In keys 1 or 2 to hear the sound, you must turn off the Audio In Thru key (the key will be dark).

The audio inputs are for line-level input. Microphones, guitars, or turntables etc. cannot be connected directly.

If the input gain setting is excessive, the sound may be distorted.

Playing with Pattern Set

What is Pattern Set?

Pattern Set is a function that lets you register a favorite pattern to each of the sixteen step keys, and use the step keys to switch patterns. You can use this function to play a performance simply by selecting patterns one after the other

When you hold down the Pattern Set key (the key will blink) and press one of the sixteen step keys, the pattern registered for that key will be selected. At this time you can use the Select keys to change the pattern set group indicated by the red select LEDs (lower line) 1..4, to use 16 x 4 (total of 64) pattern sets.



If during playback you hold down the Pattern Set key and press another step key, the pattern registered for that key will begin playing when the currently-playing pattern finishes playing. (Refer to p.31 "Pattern Set.")

If you hold down the Shift key and press the Pattern Set key, the Pattern Set function will be held. (The Pattern Set key will blink.)

To defeat this "hold" condition, press the Pattern Set key once again.

You can register new pattern sets. (Refer to p.31, "Registering a pattern for Pattern Set.")

If you switch patterns during playback, the change will occur when each pattern finishes playing. (Refer to p.22 "The timing at which patterns will changed.")



Hold down the Shift key and press the Pattern Set key to hold the Pattern Set function.

Using the ER-1 as a tone generator module



Read this section when you wish to use the ER-1 with other connected MIDI equipment. Use a MIDI cable to connect the MIDI OUT connector of your MIDI keyboard etc. to the MIDI IN connector of the ER-1.

1. Press the MIDI mode key to enter MIDI mode.
2. Use the cursor [▲][▼] keys to make the parameter select LEDs indicate **MIDI ch.**
3. Set the channel of the transmitting device to match the channel of the ER-1. (Refer to p.40 "MIDI channel settings.")
4. Use the cursor [▲][▼] keys to make the parameter select LEDs indicate **Note No.** (Refer to p.40 "Setting the MIDI note number for each part.")
5. Press the desired part key, and the note number for that part will appear in the display.


When you transmit the corresponding note from the transmitting device, the sound of that part will be played.

For details on the ER-1's MIDI functionality, refer to p.42 "About MIDI."

If you wish to save the settings of MIDI mode or Global mode, you must perform the Write operation in either of these modes. (Refer to p.39 "Saving the settings you modify in Global mode," or p.41 "Saving the settings you modify in MIDI mode.")



Check the Part Note Number




Synchronized playback with the EA-1

By synchronizing the **Electribe ER-1** and **EA-1** you can enjoy even greater performance possibilities. Here's how you can make the **EA-1** playback in synchronization with the tempo of the **ER-1**.


Use a MIDI cable to connect the **MIDI OUT** connector of the **ER-1** to the **MIDI IN** connector of the **EA-1**. Connect the line output jacks of the **ER-1** and the part output jacks of the **EA-1** to your mixer or powered monitor system (amplified speakers).

1. Press the MIDI mode key to move to MIDI mode.
2. Use the cursor [▲][▼] keys to make the parameter select LEDs indicate **MIDI ch.**
3. Set the **ER-1** channel to "01," and the **EA-1** channel to "02." (Refer to p.40 "MIDI channel settings.")
4. Press the Global mode key to move to Global mode.
5. Use the cursor [▲][▼] keys to make the parameter select LEDs indicate **Clock**.
6. Set the **ER-1** to "int," and the **EA-1** to "Ext." (Refer to p.38 "Synchronizing the ER-1 with external MIDI device.")
7. Press the Play/Pause key of the **ER-1** to start a pattern or song. (The Play/Pause key will light.) The **EA-1** will play the pattern or tempo in synchronization with the tempo of the **ER-1**.



If you want the **ER-1** and **EA-1** to play the identically-numbered pattern in synchronization, make the following settings.

- Use a MIDI cable to connect the **MIDI OUT** connector of the **EA-1** to the **MIDI IN** connector of the **ER-1**.
- Synchronizing the **ER-1** to the **EA-1** as master. (Set the **EA-1** to "int," and the **ER-1** to "Ext.")
- Set the **ER-1** and **EA-1** to the same MIDI channel (for example, set both to "01").
- On the **ER-1** and **EA-1**, set the MIDI filter setting "P" to "O" (refer to p.41 "MIDI filter settings").
- On the **ER-1**, set the MIDI note number setting to **C-1...A-1** or **A#8...G9** (refer to p.40 "Settings the MIDI note number for each part").
*This will prevent the **ER-1** from being sounded unintentionally when note-on messages are transmitted.



It is also easy to make the **ER-1** playback in synchronization by connecting it to a sequencer or synthesizer that can transmit and receive MIDI Clock messages.

Selecting parts

The ER-1 has the following eleven parts.

- Four synthesizer parts produced by analog modeling
- Two audio input parts which gate the audio signal from the AUDIO IN jacks
- Open Hi-hat, Closed Hi-hat, Crash Cymbal, and Handclap parts that use PCM waveforms
- An Accent part that contains dynamics data for each step

When you press a part key, its sound will be heard, and simultaneously that part will be selected. During playback, you can hold down the Shift key and press a part key to select that part without sounding it.

When a part is selected, its part key will light, and the step keys will show the rhythm pattern of that part. The controls of the Synthesizer section will be enabled for that part.

During playback, each part key will light at the timing with which it sounds, making it easy for you to determine which sounds are playing. The step keys will continue to show the rhythm pattern of that part, and will also indicate the rhythm location.




When you sound a part by pressing its part key, it will sound at the volume of when Accent is On.

The Part Mute function

By holding down the Part Mute key (Tap key) while you press a part key, you can mute (temporarily silence) that part.

While you hold down the Part Mute key (Tap key), the mute status of each part will be displayed. The part key of unmuted parts will light, and muted part keys will be dark.

You can also mute two or more parts. To cancel part muting, press the corresponding part key.




When you hold down the Part Mute key (Tap key) to select the Mute function, pressing a part key will not sound that part.

The Part Solo function

By pressing the Solo key (the key will light) and pressing a part key, you can hear only that part.

To solo two or more parts, hold down the Solo key and select the desired parts. While the Solo key is lit, you can hold down the Solo key (or Mute key) and press other part keys to add more solo parts. If you press and then release the Solo key, the Solo function will be canceled (the key will go dark).



When you press the Solo key, the Part Mute settings you made will be canceled (i.e., no parts will be muted).

Level 0...100

Adjust the output level. Rotating the knob toward the right will increase the volume. For the Accent part, this will adjust the Accent Level (the degree to which the volume will be emphasized when Accent is on). (Refer to p.27 "Adding accents to a rhythm pattern.")

Low Boost 0...100


This emphasizes the low-frequency range of each part. If you notice distortion (clipping) in the sound, adjust this parameter. Setting this parameter to the maximum (far right) allows it to function as a distortion effect.

 Depending on the settings of Level and other parameters, raising the Low Boost may damage your speakers or headphones etc., so please use appropriate caution.

DELAY

Delay is an effect that adds one or more delayed "echoes" to the sound. The delay effect of the ER-1 is a "cross-feedback delay." This feeds the delayed L and R signal back into the opposite side to produce a greater feeling of spaciousness from left to right.

By using the Type key to switch the type of delay, you can record delay knob movements as a Motion Sequence, or use the effect as a Tempo Delay.



 The delay effect will apply to the entire rhythm pattern, and it is not possible to change the effect independently for each part.

Type Motion Seq, Tempo Delay

Each time you press the key, the effect will alternate between Normal (LED dark), **Motion Seq**, and **Tempo Delay**. When Normal is selected, the effect will function as a conventional delay.

Motion Seq (motion sequence)

The motion sequence will control the delay (refer to p.28 "Motion Sequence").

Tempo Delay

The delay time will automatically be adjusted (synchronized) to the tempo of the pattern. If the MIDI Clock setting is "Ext," the delay time can also be synchronized to the clock of an external device. (Refer to p.38 "Synchronizing the ER-1 to a master external MIDI device.")

Depth 0...100

Adjust the level of the delay sound and the amount of feedback (the number of delay repeats).

Rotating the knob toward the right will increase the level of the delay sound, and will also increase the amount of feedback.

The further left or right the Pan of each part is set, the more the sound will be spread to left and right.

 Raising the Depth excessively may cause the sound to distort (clip).

Time (delay time) 5 msec ... 2 sec

(for tempo delay) 1/4...8

Specify the delay time. Rotating the knob toward the right will lengthen the delay time. Rotating the knob toward the left to shorten the delay time will produce a "doubling" effect (an impression as though multiple instruments are playing in unison).

If the Type parameter is set to Tempo Delay, this parameter will let you set the tempo in terms of sixteen different multiples of the tempo: 1/4, 1/3, 1/2, 2/3, 3/4, 1, 1.33, 1.5, 2, 2.5, 3, 4, 5, 6, 7, or 8.

 If you change the delay time during playback, the pitch of the delayed sound will change.



 Depending on the tempo setting, it may be impossible to set the delay time. In such cases, set the delay time to half the desired value.

Modulation

Ring Mod (ring modulation)

You can apply a ring modulation effect between two parts.

Each time you press this key, the setting will alternate between on (lit) and off (dark). By applying this to the Percussion Synthesizer parts you can create metallic sounds with a rich overtone structure. By inputting a voice to an Audio In jack, you can use ring modulation to transform the voice to a robot-like character.



 Ring modulation can be applied only between the PERCUSSION SYNTHESIZER 1 and 2, or between the PERCUSSION SYNTHESIZER 4 and AUDIO IN 1 and 2.

 The effect may be difficult to notice if the level of one signal is too low, or if the decay time is too short. When the ring modulation effect is on, the level and pan settings of PERCUSSION SYNTHESIZER 1 or of AUDIO IN 1 and 2 parts will take priority.

When ring modulation is on, no sound will be output unless both parts are played simultaneously.

Depending on the settings of both parts, very loud sounds may be output. Please adjust the level of each part appropriately.

 The tone and volume of Ring Modulation may vary depending on the timing at which Percussion Synthesizer 1 and 2 are sounded.

Creating a Rhythm Pattern

There are two ways to create a rhythm pattern. The first is Step Recording, in which you use the step keys to create the rhythm as you view the lit/unlit condition of the keys. The second is Realtime Recording, in which you strike the part keys at the timing at which you want to record each note. If you wish to erase the rhythm of each part before you create your own rhythm data, refer to p.29 "Erasing rhythm data from a part."

• Using the step keys (Step Recording)

In this method, you use the sixteen step keys to create the rhythm pattern while watching the lit/unlit condition of the keys to verify the rhythm.

For details refer to p.16 "Using the step keys to edit the rhythm (Step Recording)," in section 3. Basic operation (Quick Start).


• Using the part keys (Realtime Recording)

For details refer to p.17 "Using the part keys to edit the rhythm (Realtime Recording)," in section 3. Basic operation (Quick Start).

Adding accents to the rhythm pattern (Accent)

You can apply accents (changes in volume) to the rhythm pattern. When Accent is on, the specified notes (steps) of the entire pattern will be accented.

1. Press the Accent part key, and the accent pattern will be shown by the step keys.
2. Each time you press a step key it will alternate on/off, allowing you to specify the desired accent pattern. You can play-back the pattern to hear the results as you create the accent part.
3. The amount of the accent is adjusted by the Level knob in the synthesizer section. Rotating the knob toward the right will increase the difference between on and off. If the knob is rotated all the way toward the left, there will be no effect. Play back the pattern to hear the results as you make this setting.



Pressing the Accent part key by itself will not produce sound. Also, if a part key is struck to play the sound, it will be sounded with Accent on (i.e., the emphasized sound). If you wish to hear the results of Accent, you need to play back the pattern.



Accent level cannot be recorded in a motion sequence.

Convenient functions for editing patterns


 If you wish to save the pattern you edit using these functions, you must perform the Write operation before selecting a different pattern or turning off the power.

Erasing rhythm pattern data from a part

To erase the rhythm pattern data for the selected part, you can use one of the following two methods in addition to turning each of the sixteen step keys off.

• Erasing data during playback or recording (Erase)

1. Press a part key to select the part from which you wish to erase data.
2. During playback or recording, hold down the Shift key and press the Rec key. As long as you continue holding these keys, data will be automatically be erased from the selected part.




• Erasing all data from a part (Clear Part)

This operation erases all rhythm pattern and motion sequence data at once.

1. If the pattern is playing, press the Stop/Cancel key to stop playback.
2. Press a part key to select the part whose data you wish to erase.
3. Hold down the Shift key and press step key 12 (Clear Part). (Key 12 will blink.)
4. Once again press step key 12 to clear the data.

To cancel without clearing the data, press the Stop/Cancel key.



Moving data within a part (Move Data)

The Move Data operation lets you move the rhythm pattern and motion sequence data of a part backward or forward by -16...+16 steps.

You can use this when you want to change the starting location of a pattern.

1. If the pattern is playing, press the Stop/Cancel key to stop playback.
2. Hold down the Shift key and press step key 9 (Move Data). (Key 9 will blink.)
3. All of the part keys will blink. Each time you press a part key, it will alternate between dark and blinking. Press the part keys so that only those parts that you wish to move are blinking. (You can select two or more parts.)
4. A number will blink in the display. Rotate the dial to select the number of steps and the direction (positive or negative) in which the data will be moved.
5. Press the blinking step key 9 to execute the Move Data operation.


To cancel without executing, press the Stop/Cancel key.

The Move Data operation applied to all steps of the selected part. Data that is moved beyond the last step of the pattern will "wrap around" to the first step. For example if 64-step data is moved for "5" steps, the data that was in steps 60 through 64 will be moved to steps 1 through 5. Likewise, data that is moved earlier than the first step of the pattern will "wrap around" to the last step. For example if 48-step data is moved for "-3" steps, the data that was in steps 1 through 3 will be moved to steps 46 through 48.

With a setting of 3

The data of each step will be moved three steps toward the end of the pattern.



Example: 2 → 5, 6 → 9, 10 → 13, 14 → 1



With a setting of -2

The data of each step will be moved two steps toward the beginning of the pattern.

Example: 1 → 15, 3 → 1, 6 → 4, 10 → 8, 14 → 12



Pattern Set

Pattern Set is a function that lets you assign your favorite patterns to each of the sixteen step keys, and switch them at the touch of a key.

During playback, you can successively switch patterns to perform a song.

By using the Select key in conjunction with this to switch pattern set groups, you can register and select 16 x 4 (total of 64) patterns.

Using Pattern Set to perform (Pattern Set Play)

Press the Play/Pause key to begin playback.

Hold down the Pattern Set key and press a step key to switch to the pattern that was registered for that step key.



By holding down the Pattern Set key and pressing a Select key, you can switch to a different group of registered pattern sets. The pattern set group will be indicated by the lower line of the Select LEDs (red).

By holding down the Shift key and pressing the Pattern Set key, you can hold the Pattern Set function (the key will light).

To defeat the Hold condition, press the Pattern Set key once again (the key will go dark).

Example

Step key	1	2	3	4	5				14	15	16
Select LED											
1	A01	A20	B03	B04	A51				A20	B43	B61
2	C21	C23	C56	C64	C28				C21	A07	A08
3	B01	B02	B04	B62	A01				A05	A45	A64
4	D01	D02	D03	D04	D05				D07	D08	D09



Hold down the Shift key and press the Pattern Set key to hold the function

In Pattern Set Play, the timing at which patterns will change, tempo adjustment, and functions such as Reset & Play etc. are the same as for Pattern Play.



Pattern Set cannot be used during recording. When you enter recording (ready) mode, Pattern Set will be cancelled.

Registering a pattern for Pattern Set


1. With playback stopped, continue pressing the Pattern Set key (or Hold it) and press the step key for the location that you wish to register.
2. While continuing to press the Pattern Set key (or while Hold is still in effect), rotate the dial to select the pattern number that you wish to register. Release the Pattern Set key (or defeat Hold) to complete the registration process.
3. To save the pattern set registrations, press the Stop/Cancel key to stop playback. Continue pressing the Pattern Set key, and press the Write key (the Write key will blink).
4. The display will blink "PSt." Press the Write key once again to save the data.

To cancel, press the Stop/Cancel key.



If the Global mode Memory Protect setting is on, it will not be possible to write the data. In this case, turn off the Global mode Memory Protect setting before you execute the Write operation.

Never turn the power off during the Write operation. This may damage the data.




5. Song mode

A song consists of patterns arranged in the desired order of playback.

You can create and save up to sixteen songs in the internal memory of the ER-1. In addition to pattern playback, songs can also record rhythms and knob movements.

Press the Song mode key to enter Song mode.



Playing a song (Song Play)


Press the Play/Pause key to begin playing the song. The song will begin playing from the pattern of the currently selected position. When the song ends, playback will automatically stop.



It is not possible to save edited sounds in a song. Please use Pattern mode to edit sounds.

What is Position?

"Position" refers to the playback or recording order of the patterns within the song, and is the unit by which you edit a song.



Selecting a song

Song **S01...S16**

Use the cursor keys to make the parameter select LEDs indicate **Song**.

Rotate the dial to select one of the sixteen songs S01 to S16.

Setting the playback tempo

Tempo **20...300**

• Using the dial to set the tempo

Use the cursor keys to make the parameter select LEDs indicate **Tempo**. Rotate the dial to set the tempo.

• Using the tap tempo key to set the tempo

While the song is playing, strike the Tap key three times or more in succession at the desired tempo. The ER-1 will calculate the interval at which the Tap key was pressed, and will set the tempo accordingly. The tempo can be set in the same way even when playback is stopped.


When you use the cursor keys to make the parameter select LEDs indicate **Tempo**, and the tempo you modified will appear in the display.



If you modify the tempo of a song but then switch to another song without Writing, the first song will return to its original tempo. If you wish to keep the tempo setting you modified, you must perform the Write operation (refer to p.37 "Saving a song").

Fast-forward or rewind a song

During song playback, you can use the select keys to fast-forward or rewind. To fast-forward, press the [▶] select key. To rewind, press the [◀] select key.



Rewind Fast-forward

Switching songs

It is not possible to switch songs during playback, but it is possible to select the song number beforehand. If you select a song number during playback, the display will blink to indicate the selected number. When the currently playing song ends, playback will stop, and the newly selected number will now be steadily lit. Press the Play/Pause key to playback the selected song.

Playing from the beginning of a position or song (Reset & Play)

While a song is playing, you can hold down the Shift key and press the Play/Pause key to start playback from the beginning of the pattern specified for the currently-playing position. In addition, you can press the Play/Pause key while a song is playing to pause the playback, and then hold down the Shift key and press the Play/Pause key to playback from the beginning of the song.

Editing a song

You can insert a new pattern into a song, or delete an existing pattern. You can also add knob movements or your own performance to a song.




If you wish to keep the edited song, you must perform the Write operation. If you select a different song or turn off the power without performing the Write operation, the song will return to the state in which it was before you edited it.

Inserting a pattern at a specified position (Insert Pattern)

You can insert a pattern at a specified position, and subsequent patterns will be moved backward (toward the end of the song).

Insert a new pattern at position 3




1. If the song is playing, press the Stop/Cancel key to stop playback.
2. Hold down the Shift key and press step key 13 (**Insert Pattern**). (The 13 key will blink.)
3. The position indication in the display will blink. Rotate the dial to select the position at which you wish to insert a pattern. (For example if you wish to insert a pattern into position 3. make the display blink "003.")
4. Press step key 13 once again, and a pattern will be inserted in front of that position.

To cancel, press the Stop/Cancel key.

The pattern that is inserted will be the pattern which had previously been at that position. Now you can specify the desired pattern for the position that was inserted.


Data following the inserted pattern will be moved backward.



Deleting a pattern from a specified position (Delete Pattern)

You can delete a pattern from a specified position, and subsequent patterns will be moved forward (toward the beginning of the song).

Delete the pattern at position 5




1. If the song is playing, press the Stop/Cancel key to stop playback.
2. Hold down the Shift key and press step key 14 (**Delete Pattern**). (The 14 key will blink.)
3. The position indication in the display will blink. Rotate the dial to select the position from which you wish to delete the pattern. (For example if you wish to delete the pattern from position 5. make the display blink "005.")
4. Press step key 14 once again, and the pattern will be deleted.

To cancel, press the Stop/Cancel key.

When you delete a pattern, the event data (refer to the following page) at that position will also be deleted.

Data following the inserted pattern will be moved forward.




Deleting event data from a song (Clear Event)

This operation deletes all event data from the selected song.

1. If the song is playing, press the Stop/Cancel key to stop playback.
2. Hold down the Shift key and press step key 15 (Clear Event). (The 15 key will blink.)
3. Press step key 15 once again to clear the data.

To cancel, press the Stop/Cancel key.



Checking for song event data

If event data has been recorded in a song, holding down the Shift key and pressing the Motion Sequence key will make step keys 13 through 16 light.



It is not possible to check for event data during playback or recording.


Saving a song (Write)

If you wish to save a song that you create, you must perform this Write operation.

If you decide not to save the song data you create, simply switch songs without performing the Write operation.

1. If the song is playing, press the Stop/Cancel key to stop playback. Use the cursor keys to make the parameter select LEDs indicate **Song**.
2. Press the Write key once (the key will blink). The song number will blink in the display.
3. Rotate the dial to select the writing destination song number.
4. Press the Write key once again to save the data. (The key will light, and then go dark.)

To cancel, press the Stop/Cancel key.



If the Global mode Memory Protect setting is on, it will not be possible to write the data. In this case, turn off the Global mode Memory Protect setting before you execute the Write operation.


Never turn the power off during the Write operation. This may damage the data.

Synchronizing an external MIDI device to the ER-1 as master (int)

1. Use a MIDI cable to connect the **MIDI OUT** connector of the **ER-1** to the **MIDI IN** connector of the external MIDI device (sequencer or synthesizer etc.).
2. Use the cursor keys to make the parameter select LEDs indicate **Clock**.
3. Rotate the dial to select "**Int**" (internal clock).
4. Make settings on the external MIDI device (slave) so that it will receive MIDI Clock messages.
5. When you start playback on the **ER-1**, the external MIDI device will begin playback in synchronization.



When you perform the Reset & Play operation to begin playback from the beginning of the pattern, the ER-1 will transmit only a MIDI Start message.



Protect settings (Memory Protect)

Protect

on, oFF

This is the memory protect setting for Pattern mode and Song mode. When protect is "**on**," the Write key will not function, and it will not be possible to rewrite data or to receive MIDI data dumps.

If you wish to save data you edited or to receive a data dump, you must turn protect "**oFF**."


1. Press the Stop/Cancel key to stop playback.
2. Use the cursor keys to make the parameter select LEDs indicate **Protect**.
3. Rotate the dial to turn Protect "**on**" or "**oFF**."

If you wish to save the Protect setting, perform the Global mode Write operation.



This setting applies to Pattern mode and Song mode. In Global mode and MIDI mode, it is always possible to Write data regardless of the Protect setting.

With the factory settings, this will be "on."



Saving the settings you modify in Global mode (Write)



When you perform the Write operation in either Global mode or MIDI mode, the modified settings of both modes will be saved.

Here's how to save the Global mode settings. If you wish to save the settings you modify, you must perform this Write operation. Each time you turn on the power, those settings will be in effect. Conversely, if you do not wish to save the modified settings, simply turn off the power without performing the Write operation.

1. Press the Stop/Cancel key to stop playback.
2. Press the Global mode (or MIDI mode) key.
3. Press the Write key once (the key will blink). The display will indicate "---."
4. Press the Write key once again to write the data.

To cancel, press the Stop/Cancel key.

In Global mode or MIDI mode, it is always possible to execute the Write operation, regardless of the Protect settings (see the previous section).




Never turn off the power while data is being written to memory. This may damage the data.

MIDI filter settings

Here you can select the types of MIDI message that will be transmitted and received.

For each character "PCE" in the display, select "O" if you want that type of message to be transmitted and received, or select "-" if you do not want that type of message to be transmitted or received.

1. Use the cursor keys to make the parameter select LEDs indicate **MIDI Filter**.
2. Rotate the dial to select the combination of message types that will be transmitted and received; "O" allows transmission and reception, and "-" disables it.
 - P: Transmission/reception of Program Change, Bank Select, and Song Select messages.
 - C: Transmission/reception of Control Change messages.
 - E: Transmission/reception of Exclusive data. However when the parameter select LEDs indicate **Dump**, Exclusive data can be transmitted/received regardless of this setting.



Saving the settings you modify in MIDI mode (Write)



When you perform the Write operation in either MIDI mode or Global mode, the modified settings of both modes will be saved.

Here's how to save the MIDI mode settings. If you wish to save the settings you modify, you must perform this Write operation. Each time you turn on the power, those settings will be in effect. Conversely, if you do not wish to save the modified settings, simply turn off the power without performing the Write operation.

1. Press the Stop/Cancel key to stop playback.
2. Press the MIDI mode (or Global mode) key.
3. Press the Write key once (the key will blink). The display will indicate "---."
4. Press the Write key once again to write the data.

To cancel, press the Stop/Cancel key.

In Global mode or MIDI mode, it is always possible to execute the Write operation, regardless of the Protect settings (see the previous section).



Never turn off the power while data is being written to memory. This may damage the data.

the location at which playback will start, and then playback in synchronization. If you use the dial or Select keys to fast-forward or rewind while the song is playing, Song Position Pointer messages will not be transmitted. Be aware that if you perform these operations during synchronized playback, the synchronization will be lost. Also, even if Song Position Pointer messages are received during playback, the playback location will not change.

8. About system exclusive messages

Manufacturers are free to use system exclusive messages in any way they choose, and these messages are used mainly to transmit and receive parameters that are specific to particular devices, such as sound data and editing data.

The system exclusive message format of the ER-1 is [F0, 42, 3n, 51, ... F7] (n: exclusive channel).

However, some system exclusive messages have been defined for use in a specific way, and these are called "universal system exclusive messages."

Of the several different universal system exclusive messages, the ER-1 supports the following one.

- When an Inquiry Message Request [F0, 7E, nn, 06, 01, F7] is received, the ER-1 will transmit an Inquiry Message [F0, 7E, nn, 06, 02, (nine bytes), F7] that means "I am a Korg ER-1 and my system version is ..."

9. Transmitting sound setting data (Data Dump)

Song, Pattern, or All (song, pattern, global) data can be transmitted as MIDI exclusive data, and stored on an external device. This data is transmitted by the MIDI mode Dump command. The channel used for transmission and reception of this data is set by the MIDI mode MIDI ch setting. Data dumps are also transmitted when a Data Dump Request message is received.

10. Editing sounds etc.

By sending MIDI exclusive data dumps, you can rewrite all patterns or individual programs. By using NRPN messages in Pattern mode, you can edit the knobs that are active for each part.

Troubleshooting

The display does not light up when I press the Power switch!

- Is the AC adapter connected?
- Is the AC adapter plugged into an AC outlet?

No sound!

- Is your amp, mixer, or headphones connected to the correct jack? (Can you playback a pattern? If so, the connections are correct.)
- Are your amp or mixer powered-on and set correctly?
- Is the master volume knob of the ER-1 raised?

Sound does not stop!

- When a pattern is played back, it will continue playing repeatedly. When you are finished listening to a pattern, press the Stop/Cancel key (p.12, 13).

Sounds or operations are different than when I edited!

- Did you perform the Write operation after editing? (p.32, 37) After you have edited, you must perform the Write operation before switching songs or patterns, or turning off the power.
- Did you edit the selected pattern or song after writing it?

Can't control via MIDI!

- Is the MIDI cable or special cable connected correctly?

When playing the ER-1 from an external device

- Has the ER-1 been set to receive MIDI data on the channel on which the data is being transmitted? (p.40)
- Is the MIDI mode MIDI Channel parameter set to the desired channel? (p.40)
- Are the MIDI mode MIDI Filter settings set appropriately? (p.41)

When playing an external device from the ER-1

- Does the MIDI channel of the ER-1 match the MIDI channel of the receiving device? (p.40)

Can't write a pattern or song!

- Is the Global mode Protect setting turned "on"? (p.39)

Striking a part key does not play the specified drum sound!

- After editing the sound of a part, did you perform the Write operation? (p.32)
- Is the Ring Mod key on? (p.25)
- Is a motion sequence operating? (p.28)

Example sounds

Analog Kick 1

Parameter control panel for Analog Kick 1. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Analog Kick 2

Parameter control panel for Analog Kick 2. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Analog Snare 1

Parameter control panel for Analog Snare 1. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Analog Snare 2

Parameter control panel for Analog Snare 2. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Electric Tom

Parameter control panel for Electric Tom. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Analog Cowbell

Parameter control panel for Analog Cowbell. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Zap

Parameter control panel for Zap. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

Noise Shot

Parameter control panel for Noise Shot. The panel is divided into three main sections: OSCILLATOR, AMP, and DELAY. The OSCILLATOR section includes Pitch, Mod Depth, Mod Speed, Wave (with a square wave icon), and Mod Type (with a square wave icon). The AMP section includes Decay, Level, Pan, and Low Boost. The DELAY section includes Motion Seq (with a square wave icon), Type (with a square wave icon), and Depth and Time knobs.

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

OSCILLATOR			AMP		
<input checked="" type="checkbox"/> Original Value					
	<input type="checkbox"/> Smooth <input type="checkbox"/> Trig Hold		<input type="checkbox"/> Motion Seq <input type="checkbox"/> Tempo Delay		

Pattern Set ----- 11, 20, 31
 Play ----- 20, 31
 Registering ----- 31
 Write ----- 31
 Peak ----- 9, 19
 Peak LED ----- 9
 PERCUSSION SYNTHESIZER
 ----- 9, 19
 Pitch ----- 8, 24
 Play
 Motion Sequence ----- 18, 28
 Pattern ----- 13, 22
 Song ----- 12, 33
 Position ----- 33
 Protect ----- 39

R

Realtime Recording ----- 17, 27
 Reception ----- 40
 Recording
 Event ----- 36
 Realtime ----- 17, 27
 Step ----- 16, 27
 Registering
 Pattern Set ----- 31
 Reset&Play ----- 22
 Restoring the factory set ---- 44
 Rewind(REW) ----- 33
 Rhythm Pattern ----- 16, 27
 Ring modulation ----- 9, 25

S

SCALE/BEAT ----- 16, 26
 Select ----- 10
 Shift ----- 8, 11
 Smooth ----- 28
 Solo ----- 10, 23
 SONG ----- 9, 12, 33
 Song
 Clear ----- 34
 Event ----- 36
 Fast-forward ----- 33
 Mode ----- 33
 Play ----- 33
 Protect ----- 39
 Reset&Play ----- 33
 Rewind ----- 33
 Tempo ----- 13, 33
 Write ----- 37
 Specifications ----- 44
 Step Recording ----- 16, 27
 Swing ----- 26
 Synchronized playback ----- 21

Synchronizing ----- 38
 Synthesizer ----- 8, 14
 System Exclusive ----- 42

T

TAP ----- 10, 13, 22, 33
 Tempo
 DELAY ----- 25
 Pattern ----- 13, 22
 Song ----- 13, 33
 Tap ----- 10, 13, 22, 33
 Tempo Delay ----- 25
 Time ----- 8, 25
 Transmission ----- 40
 Trig Hold ----- 28
 Troubleshooting ----- 43
 Type ----- 8, 25

W

Wave ----- 8, 24
 WRITE ----- 10
 Write
 Global ----- 39
 Song ----- 37
 Pattern ----- 18, 32
 Pattern Set ----- 31
 MIDI ----- 41

Function ...		Transmitted	Recognized	Remarks
Basic channel	Default Changed	1 – 16 1 – 16	1 – 16 1 – 16	Memorized
Mode	Default Messages Altered	×	3 ×	
Note number :	True voice	0– 127	9n, v=1– 127	Specified by MIDI mode for each part
Velocity	Note ON Note OFF	9n, v=30 – 127 ×	9n, v=1 – 127 ×	Transmitted velocity is specified by Accent level
After Touch	Polyphonic Channel	× ×	× ×	
Pitch Bender		×	×	
Control Change	0,32 98, 99 8	○ ○ ○	○ ○ ○	Bank Select(MSB,LSB) *P NRPN(LSB,MSB) *C Data Entry(MSB) *C
Program Change :	True#	○ 0 – 127 *****	○ 0 – 127 0 – 127	Transmitted/received in Pattern mode *P
System Exclusive		○	○	Can always be transmitted/received in the MIDI Dump page *2 *E
System Common	: Song Pos : Song Sel : Tune	○ ○ 0 – 15 ×	○ ○ 0 – 15 ×	Transmitted/received in Song mode *1 *P
System Realtime	: Clock : Commands	○ ○	○ ○	*1 *1
Aux Messages	: Local ON/OFF : All Notes OFF : Active Sense : Reset	× × ○ ×	○ ○123-127 ○ ×	
Notes	<p>*P, *C, *E: Sent and received when MIDI mode MIDI Filter (P, C, E) respectively are set to "O"</p> <p>*1: Sent but not received when Global mode Clock is "Int." When set to "Ext," received but not sent.</p> <p>*2: In addition to Korg exclusive messages, also responds to Inquiry messages.</p>			

Mode 1: OMNI ON, POLY
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO
Mode 4: OMNI OFF, MONO

○ : Yes
× : No

* Consult your local Korg distributor for more information on MIDI IMPLEMENTATION.

NOTICE

KORG products are manufactured under strict specifications and voltages required by each country. These products are warranted by the KORG distributor only in each country. Any KORG product not sold with a warranty card or carrying a serial number disqualifies the product sold from the manufacturer's/distributor's warranty and liability. This requirement is for your own protection and safety.

KORG KORG INC.

15 - 12, Shimotakaido 1 - chome, Suginami-ku, Tokyo, Japan.